



CATSCRATCH DOOR CUT-OUT TEMPLATE

1. FOLD TEMPLATE ON THE DASHED LINE BELOW. USE SCISSORS TO CUT AROUND THE SOLID LINE OF THE TEMPLATE AND REMOVE THE OUTER STRIP.
2. DETERMINE THE DESIRED LOCATION OF HOLE-OPENING ON THE BOTTOM OF THE DOOR.
3. POSITION TEMPLATE SO THAT THE FOLDED DASH LINE ALIGNS EVENLY WITH THE BOTTOM OF THE DOOR.
4. CAREFULLY TRACE THE HOLE OUTLINE ON THE DOOR.
5. DARKEN THE HOLE OUTLINE ON THE DOOR SO THAT IT CAN BE EASILY SEEN WHEN SAWING.
6. BEFORE SAWING - DOUBLE CHECK TO ENSURE THAT YOU TRACED CORRECTLY BY PLACING THE FRAME OVER THE TRACED HOLE OUTLINE (FRAME SHOULD COVER THE HOLE OUTLINE).
7. CAREFULLY SAW AROUND THE HOLE OUTLINE. NOTE: YOU MAY WANT TO COVER THE SAW BASE WITH MASKING TAPE TO AVOID SCRATCHING THE DOOR SURFACE.

PAWS & PALS
just for them

FOLD ALONG DOTTED LINE